

VD6953 Lens Shading Correction Guide


Introduction

This apps note is intended to help the user calculate the parameters required for lens shading correction for the VD6953. It will attempt to cover both laboratory and production methods.

The VD6953 can utilise an advance on-chip lens shading correction algorithm, known as the 'AV2x2' block. In addition there is a green imbalance corrector before the EDOF block which helps the EDOF performance. This corrector is known as the 'gimbal' block.



The VD6953 uses an adaptive algorithm driven by white balance gains from the host. There are 4 sets of parameters held for both gimbal and av2x2, one set per colour temperature. As the scene changes the adaptive algorithm interpolates between the 2 nearest sets of data. An index is required for each colour temperature, this is the normalised red gain (r-norm) based on the white balance gains from the host.



1 Laboratory based method

1.1 Image Capture

Completely flat images should be captured under four different colour temperatures. One easy method of doing this is to place a diffuser directly over the lens in a light box. There are a few requirements for the image capture:

- Pedestal **MUST** be zero
- Images should be 10-bit .pgm file
- Analogue gain should be set at 1.0
- Maximum pixel level should not be greater than 80% (i.e. approx 800 codes in the green channel at the centre of image)
- All on-chip correction (i.e. Gimbal and AV2x2) **MUST** be disabled


Table 1. Registers relevant to image capture

| Register Address | Register Name | Register Settings | Comments |
|------------------|---------------------------|-------------------------------|--|
| 0x0b00 | shading_correction_enable | 0x00: Disable 0x01: Enable | Set to 0x00 to turn off the AV2x2 correction block |
| 0x0205 | analogue_gain_code | Range: 0x00 to 0xf0 | Set to 0x00 to make analogue gain = 1 |
| 0x31e8 | clip1_enable | 0x00: Disable 0x01: Enable | Set to 0x00 to ensure that output data has a pedestal of 0 |
| 0xfaa3 | mapped_gimbal_enable | 0x00: Disable 0x01: Enable | Set to 0x00 to turn off the gimbal correction block |

One of the easier ways to capture the images is to use ST's 'Druid' software. At the time of writing the current version is 'STsp_Full 1.0.3'. The software should be run in default mode with the following changes (must be stopped before changes are applied):

- Load '953_Sensor_Plug-in.xml' configuration
- Full resolution (singleread mode)
- Use V2WREG to set the registers as detailed in [Table 1](#) (except analogue gain)
- Use the exposure controls to set the max user analogue gain to 1.0
- Capture images from output of 'sensor953' block - this will be a 10 bit raw bayer .pgm file

Shown here is a screen capture of the Druid software. It is the lower right image that should be saved.



The Druid software allows the generation of gimbal and av2x2 parameters based on the saved images (using the avGen module). There is a separate step by step guide showing this process available on the 953 apps support pages. The advantage of this method is that there is also a facility to convert the dat files to v2wreg scripts (dat2wreg module).

Another method is to use the AVPG (anti-vignette parameter generation) .dll wrapped in a command line based executable. This program is called 'av_param_gen.exe'. The AVPG folder should be copied anywhere on the PC (in the following example it was copied to the root C drive, 'C:\AVPG').

The simplest way to use the command line executable is to write a batch (.bat) file to automate the generation of parameters. In this example the .bat file was placed in the same folder as the captured images so there was no need for a path before the image name.

The program is called twice per image. The first time it generates and applies the gimbal parameters (mode 3), the second pass uses this intermediate image and generates the av2x2 parameters (mode 4).

1.1.1 Example Script

```
rem generates gimbal and av2x2 parameters for 953 from diffuse images (.pgm)
rem images must have a pedestal of 0

rem gimbal - generates intermediate files that have been gimbal corrected
C:\avp\glav_param_gen -mode 4 -improc 953_d65.pgm 953_d65_gimbal.pgm > d65_gimbal.dat
C:\avp\glav_param_gen -mode 4 -improc 953_cwf.pgm 953_cwf_gimbal.pgm > cwf_gimbal.dat
C:\avp\glav_param_gen -mode 4 -improc 953_incA.pgm 953_incA_gimbal.pgm > incA_gimbal.dat
C:\avp\glav_param_gen -mode 4 -improc 953_hor.pgm 953_hor_gimbal.pgm > hor_gimbal.dat

rem av2x2 - uses the intermediate gimbal files to generate av2x2 params
C:\avp\glav_param_gen -mode 3 -bowl 0.95 953_d65_gimbal.pgm > d65_av2x2.dat
C:\avp\glav_param_gen -mode 3 -bowl 0.95 953_cwf_gimbal.pgm > cwf_av2x2.dat
C:\avp\glav_param_gen -mode 3 -bowl 0.95 953_incA_gimbal.pgm > incA_av2x2.dat
C:\avp\glav_param_gen -mode 3 -bowl 0.95 953_hor_gimbal.pgm > hor_av2x2.dat

rem delete the intermediate images
del 953_d65_gimbal.pgm
del 953_cwf_gimbal.pgm
del 953_incA_gimbal.pgm
del 953_hor_gimbal.pgm

pause
```

In this example of bowl % of 95% (0.95) was used. From experience this normally gives good results, but anywhere between 75% and 100% may give the desired results. The bowl percentage is the target for the corner brightness compared to the centre.

1.1.2 Output Format

The output from the script is two text files per colour temperature, one for gimbal parameters and one for av2x2.

Gimbal:

```
AvGenRaw shared library v1-02
MODE IS 4, ISP is 6, JOBSIZE is 7
R2s 8 PARA 0
JOBSIZE 7 (GR_HOT 1)
GR: 0 0 8 5 0 -4 4
RR: 0 0 0 0 0 0 0
BB: 0 0 0 0 0 0 0
GB: 0 0 0 0 0 0 0
MSE: [GR 1.54] [RR 0.00] [BB 0.00] [GB 0.00]
```

The Gimbal parameter order is:

Unity x x2 x3 y y2 y3

AV2x2:

AvGenRaw shared library v1-02
 MODE IS 3, ISP is 6, JOBSIZE is 9
 R2s 8 PARA 0
 JOBSIZE 9 (GR_HOT 1)
 GR: 1-38120-54 43-12158 -8-170
 RR: 0-32216-82 -4 32287-42-412
 BB: 0 17100-39-42-66137-63-115
 GB: 0-36119-53 48-12158-31-171
 MSE: [GR 6.64] [RR 11.61] [BB 6.86] [GB 6.58]

The AV2x2 parameter order is:

Unity x x2 y xy yx2 y2 y2x y2x2

These parameters are then ready to be either loaded temporarily into the device using I2C writes or can be programmed into NVM at the relevant locations.

1.1.3 GR/GB select registers

Gimbal operates only on one of the green colour planes; either GR or GB. If the output data is in the GR channel, then the GIMBAL_CHANSEL register {0x3411} must be set to 0x00, if the data is on the GB channel, it must be set to 0x03.

The AV2x2 unity offset likewise only operates on either the GR or GB colour plane. The output data will only have a unity offset on one of the channels, if it is on the GR channel, then the AV2x2_UNITY_GSEL register {0x318b} must be set to 0x00, if the data is on the GB channel, it must be set to 0x01.

1.1.4 Calculation of colour cast indices

Each set of parameters needs to be associated with a normalised red gain. Again these indices must be programmed into NVM at the appropriate location. These can be calculated as the same time as the images are captured. Within Druid there is an 'imageStats' metric that can be used to calculate the normalised red gain (although the avGen tool does this automatically).

When the images are captured, there is no lens shading correction applied. It is therefore important to only use stats from the central 1% area. An ROI of 260 x 196 should be created with the top left hand corner at (1174, 882):

rect 'roi 1' Properties

Name: roi 1

Bounding Box


| | | | |
|--------|------|---------|------|
| Left: | 1174 | Top: | 882 |
| Right: | 1433 | Bottom: | 1077 |
| Width: | 260 | Height: | 196 |

Definition Vertices

| | x | y |
|----|------|------|
| 0: | 1174 | 882 |
| 1: | 1434 | 882 |
| 2: | 1434 | 1078 |
| 3: | 1174 | 1078 |

Close

The output from the imageStats metric should look like this:



The screenshot shows the 'imageStats (FLAVOURLESS_2.0.0)' window. The 'input' field is set to 'benchCfgIspStsp5n953.config.isp.channeloffsets.output [C]'. The 'selection' dropdown is set to 'roi 1'. The 'output' section displays a table with the following data:

| | Min | Max | Mean |
|----------|--------|--------|--------|
| roi 1.Gr | 678.00 | 735.00 | 705.95 |
| roi 1.R | 506.00 | 588.00 | 546.08 |
| roi 1.B | 441.00 | 515.00 | 476.32 |
| roi 1.Gb | 680.00 | 734.00 | 705.97 |

To calculate the normalised red gain, first the channel gains must be calculated. This should be done in the same way as the host processor will calculate them as it is the host that feeds the channel gains back to the 953.

If we assume a simple grey world white balance, then the channel gains would be calculated as follows:

$$\text{GrGain} = \frac{\text{Max}(\text{Gr}, \text{R}, \text{B}, \text{Gb})}{\text{Gr}}$$

$$\text{RGain} = \frac{\text{Max}(\text{Gr}, \text{R}, \text{B}, \text{Gb})}{\text{R}}$$

$$\text{BGain} = \frac{\text{Max}(\text{Gr}, \text{R}, \text{B}, \text{Gb})}{\text{B}}$$

$$\text{GbGain} = \frac{\text{Max}(\text{Gr}, \text{R}, \text{B}, \text{Gb})}{\text{Gb}}$$

The normalised red gain would then be calculated thus:

$$\text{rnorm} = \frac{\text{RGain}}{\text{RGain} + \text{GGainav} + \text{BGain}}$$

Where GGainav is the average of the two green channel gains.

So in the example above r-norm = 0.342 (image captured in office lighting).

This number must be multiplied by 256 before being programmed into NVM.

Typical values for the 4 colour casts will typically be approx:

- Cast 3 (D65) 0.44
- Cast 2 (CWF) 0.35
- Cast 1 (IncA) 0.26
- Cast 0 (HOR) 0.22

The exact values will be determined by the light source used and the optical properties of the lens and IR glass.

2 Notes for Production


During FMT (final module test), the techniques required for lens shading parameter generation will need to be modified depending on the production environment used.

The same .dll file is used, but it will need to be included in the production test environment. The main difference is that during production it may not be possible in terms of time or equipment to capture images under 4 different colour temperatures. Assuming only 1 colour temp is used, the other 3 sets of parameters can be calculated based on data collected from several modules which have been measured under 4 colour temp.

The capture of images must obey the same rules as the lab method, but because Druid will not be used, the exposure will have to be set by the production test software.

To avoid having to remove the pedestal of 64 in software, it is possible to set register 0x31e8 to 0x0. This will ensure that the output data has 0 pedestal.

For calculation of the colour cast indices, it may be easier to split the image into 4, one per colour plane. Then a centre region of 130 x 98 (1% area) can be measured in each image to obtain the average pixel value. From this the r-norm (colour cast indices) values can be calculated.



The white balance method used should be the same as the host processor will use as it is the host that will write the channel gains to the sensor during normal operation. It may be acceptable to use a simple grey world white balance as outlined in [Section 1.1.4](#).

3 Revision history

Table 2. Document revision history

| Date | Revision | Changes |
|--------------|----------|--|
| 04-June-2010 | 0.1 | Initial release. |
| 10-June-2010 | 0.2 | Minor changes & added normalised red gain calculation section. |
| 07-Jul-2010 | 0.3 | Added GR/GB gimbal & AV2x2 select. |
| 17-Jul-2010 | 0.4 | Corrected colour index calculation. |
| 30-Jul-2010 | 0.5 | Updated Druid section. |
| 08-Aug-2010 | 0.6 | Corrected colour cast index order. |

Confidential

CONFIDENTIALITY OBLIGATIONS:

This document contains sensitive information.
Its distribution is subject to the signature of an Non-Disclosure Agreement (NDA).
It is classified "**CONFIDENTIAL**".

At all times you should comply with the following security rules
(Refer to NDA for detailed obligations):

Do not copy or reproduce all or part of this document
Keep this document locked away

Further copies can be provided on a "need to know basis", please contact your local ST sales office.

Please Read Carefully:

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.

UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED ST REPRESENTATIVE, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2010 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

www.st.com

